

# Color CCD Camera [For Outdoor Camera] Model: DRC-4CM

## Use and C

Before operating the unit, please read the future reference

#### Introduction

Your unit is designed so it can be flush mounted on the wall or used. When flush mounted cunit for angular of unit view. The model number is located on the bottom and record the seri (available). Refer to these numbers whenever you call upon your Commax dealer regarding thi

To prevent fire or shock hazard, do not expose the unit to rain or moisture.



Model No.

# CAUTION RISK OF ELECTRIC SHOCK

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE

DO NOT OPEN



This symbol is intended to alert "dangerous Voltage" within t

sufficient magnitude to constitut

Serial No.



This symbol is intended to aler operating and maintenance (

#### Important Safeguard

**Damage Requiring Service -** This equipment from the power source and refer servicing to following conditions:

- a. when the power is damaged;b. if liquid has been spilled or objects have fallen into the unit.;
- c. if the equipment has been exposed to rain or water;
- d. if the equipment has been dropped or otherwise damaged;

e. when the equipment exhibits a distinct change in performance - this indicates a need for sen


**Water and Moisture -** Do not use this product near water, for example, near a bath tub, wash wet basement, or near a swimming pool, and the like.

Accessories - The product may fall, causing serious injury to a child or adult, and serious dar


the appliance should follow the manufacture's instructions, and should use a mounting accesso

Object and Liquid Entry - Never push objects of any kind into this product through opening

#### **Location And Function of Controls**



· · ·



Side Cover

Speaker

#### Note On Use And Installation

### Do Not Aim The unit At The Sun/Rainning

Do not aim the unit at the sun or point it at the sun/rainning even if you are not shooting.

Framing intense light such as a spotlight may cause bloom or smear. A vertical stripe may app

#### Do Not Shoot Intense Light

malfunction.

## Treat The Unit With Care

# Do not drop the unit or subject it strong shock of vibration. Otherwise, the components may may

Never Touch Internal Parts


Do not touch the internal parts of the camera other than that parts specified. Otherwise, the car

## Check The Ambient Temperature And Humidity

Avoid using the camera where the temperature is hotter or colder than specified. Otherwise, to internal parts may be affected. Special care is required to use the camera at high temperature.

#### System Network And Camera Height Level

- 1. Fixed with the bracket on flush box (Screw -T4 x 18mm) (as shown below).
- 2. Checking to polarity that conection to monitor before installation.
- 3. When connect the retifier, reference as drawing below.
- 4. Remove the side cover from the unit, use screw (M3 x 8mm) supplied) and unit attached on the



#### Specification Model No. DRC- 4CM Pick-ip Device 1/3" Color CCD Camera **Power Sources** DC 13V (Power supplied from the monitor) 4 Wires Polarity/2Wires Non-polarity Wire Installation Minimum Illumination 0.11uxCommunication Ways Synchronous Communications

Hori./Vert. Frequency 15.734KHz/60Hz

Illumination Built - in L.E.D On Night (Below 5.0 lux) Operating Adjust Angular Field Of View Horizontal: 68 Vertical: 55

**Ambient Operating Temperature** -10, C to +50, C

160 (Included Bracket)

83/125/40

Dimensions (W/H/D)mm

Weight (g)

